



PHYSICAL PROPERTIES

Appearance: Clear Red Liquid

Specific Gravity: 1.27

Odor: Characteristic

Ph (Conc.): 0-1

Flash Point: N/A

PACKAGING

4X1 gal, 5 gal, 55 gal

F-200

FOAMING ACID CLEANER

ABOUT THIS PRODUCT

F-200 is an economical, concentrated, high performance foaming cleaner formulated with a non-fuming acid solution. This combination results in a product that is non-irritating to breathe, yet performs well in many industrial and institutional applications. It is high foaming cleaner and metal brightener. Excellent for removal of calcium, scale, and rust.

Use in: Dairy Farms, Meat & Poultry Processing Plants, Bottling Plants, Breweries and Wineries, Bakeries, Eating & Drinking Establishments, Nursing Homes & Hospitals and Supermarkets.

DIRECTIONS

CIP SCALE REMOVER: Flush system with water. Dilute F-200 at a rate of 1:3 up to 1:6 with water. Circulate through the system for 20 minutes to 1 hour. Drain. Rinse well.

FOR REMOVAL OF CALCIUM AND PROTEIN SCALE: Dilute F-200 1 part with 3 parts of water. Thoroughly wet the equipment surface with this solution. Allow 10 minutes soaking time. Scrub with natural bristle brush. Rinse thoroughly with fresh water.

TO BRIGHTEN METAL SURFACES: Dilute F-200 with 2 to 3 parts of water. Thoroughly wet the surface. Allow solution to remain on surface, scrub with a brush until metal surface is brightened to the desired degree. Rinse thoroughly with water.

DISHWASHING MACHINES: Add 1 to 1.5 gal. of F-200 to water in machine and operate until lime deposits are dissolved. Drain and refill with clean water. Operate machine 5 minutes and drain.

PRECAUTIONARY STATEMENTS

Prevention: Keep only in original container. Do not breathe dusts or mists. Wash skin thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection. **Response:** Absorb spillage to prevent material damage. Call a POISON CENTER/doctor/medical professional if you feel unwell. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable breathing. Immediately call a POISON CENTER/doctor/medical professional. Specific treatment (see section 4 on the Safety Data Sheet). IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing. **Storage:** Store in corrosive resistant container with a resistant inner lining. Store locked up. **Disposal:** Dispose of contents/container in accordance with local/regional/national/international regulations.

CUI Solutions, Inc.

1841 VERNON ST. | N. KANSAS CITY, MO 64116 | 816-471-3602
FAX: 816-474-3302 | WWW.CUISOLUTIONS.COM