



PHYSICAL PROPERTIES

Appearance: Clear Liquid Specific Gravity: 1.27 Odor: Characteristic Ph (Conc.): 0-1 Flash Point: N/A

PACKAGING

4X1 gal, 5 gal, 55 gal

F-280 NON-FOAMING ACID CLEANER

ABOUT THIS PRODUCT

F-280 is an economical, concentrated, high performance cleaner formulated with a non-fuming acid solution. This combination results in a product that is non-irritating to breathe, yet performs well in many industrial and institutional applications. It is low foaming for use in CIP cleaning and metal brightening. Excellent for removal of calcium, scale, and rust.

Use in: Dairy Farms, Meat & Poultry Processing Plants, Bottling Plants, Breweries and Wineries, Bakeries, Eating & Drinking Establishments, Nursing Homes & Hospitals and Supermarkets.

DIRECTIONS

CIP SCALE REMOVER: Flush system with water. Dilute F-280 at a rate of 1:3 up to 1:6 with water. Circulate through the system for 20 minutes to 1 hour. Drain. Rinse well.

FOR REMOVAL OF CALCIUM AND PROTEIN SCALE: Dilute F-280 1 part with 3 parts of water. Thoroughly wet the equipment surface with this solution. Allow 10 minutes soaking time. Scrub with natural bristle brush. Rinse thoroughly with fresh water.

TO BRIGHTEN METAL SURFACES: Dilute F-280 with 2 to 3 parts of water. Thoroughly wet the surface. Allow solution to remain on surface, scrub with a brush until metal surface is brightened to the desired degree. Rinse thoroughly with water.

DISHWASHING MACHINES: Add 1 to 1.5 gal. of F-280 to water in machine and operate until lime deposits are dissolved. Drain and refill with clean water. Operate machine 5 minutes and drain.

PRECAUTIONARY STATEMENTS

Prevention: Keep only in original container. Do not breathe dusts or mists. Wash skin thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection. **Response:** Absorb spillage to prevent material damage. Call a POISON CENTER/ doctor/medical professional if you feel unwell. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable breathing. Immediately call a POISON CENTER/doctor/medical professional. Specific treatment (see section 4 on the Safety Data Sheet). IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing. **Storage:** Store in corrosive resistant container with a resistant inner lining. Store locked up. **Disposal:** Dispose of contents/container in accordance with local/regional/ national/international regulations.