



Fiber Rinse

DETERGENT RINSE & NEUTRALIZER



PHYSICAL PROPERTIES

Appearance: Pink Liquid

Specific Gravity: 1.04

Odor: Pleasant

Ph (Conc.): 1-2

Flash Point: N/A

PACKAGING

4x1 gal, 5 gal, 55 gal

ABOUT THIS PRODUCT

Fiber Rinse is a specially formulated rinsing solution designed to be used in the final step of wet cleaning. Fiber Rinse neutralizes alkalinity and removes detergent residues, leaving fibers pH-balanced, clean and soft. As a dye stabilizer, Fiber Rinse will restrict color bleeding and help prevent browning. Effectively used on carpet and upholstery. Using Fiber Rinse leaves fibers and fabrics in an acid state after cleaning and will help to prevent browning.

Use Fiber Rinse on Carpets, Upholstery, Urine, Road Salt, Calcium Chloride, Stabilize Dye, Browning Preventive, Rinsing Agent. Use Fiber Rinse to eliminate carpet stains left by ice melting residue, use 1 to 3 ounces per gallon of water in carpet extraction equipment. A color fastness test in a hidden area should always be performed before extraction on carpet and upholstery.

DIRECTIONS

Truck Mounts: Mix 1 quart per 5 gallons of water to make a Truckmount concentrate (20:1). Set chemical injection flowmeter at 2 gallons per hour, extract.

For Spray Rinse: Mix 1 oz. per gallon of water (128:1). Apply 1 gallon Ready-to-Use per 200-500 sq. ft. (depending on the pile density). Vacuum extract or rake into carpet for maximum performance

PRECAUTIONARY STATEMENTS

Prevention: Keep only in original container. Do not breathe dusts or mists. Wash skin thoroughly after handling. Wear protective gloves/ protective clothing/ eye protection/face protection. **Response:** Absorb spillage to prevent material damage. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable breathing. Immediately call a POISON CENTER/doctor/medical professional. Specific treatment (see supplemental information on this label). IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing. **Storage:** Store in corrosive resistant container with a resistant inner lining. Store locked up. **Disposal:** Dispose of contents/container in accordance with local/ regional/national/international regulations.

CUI Solutions, Inc.

1841 VERNON ST. | N. KANSAS CITY, MO 64116 | 816-471-3602
FAX: 816-474-3302 | WWW.CUISOLUTIONS.COM