



105

NEUTRAL CLEANER



PHYSICAL PROPERTIES

Appearance: Green Liquid

Specific Gravity: 1.01

Odor: Fresh

Ph (Conc.): 7-8

Flash Point: >385°F (196°C)

PACKAGING

4X1 gal

ABOUT THIS PRODUCT

LockNLoad 105 Neutral Cleaner is a low-foaming nonionic surfactant with exceptional grease-cutting performance. LockNLoad 105 will not streak, haze or leave a detergent film residue on cleaned surfaces. This gentle cleaner is ideal for damp mopping floors, it picks up dirt and grime without harming floor finishes. It has a mild detergent that is gentle to all washable surfaces yet strong enough to remove tough dirt and soils.

DIRECTIONS

Insert container into the LockNLoad Dilution Station. Lock the container into place by sliding the blue lock to the left. This locks in the container and connects it to the Dilution Station. The Dilution Station is set to properly dilute the concentrate with water.

To fill small containers by using the short hose on the right side of the Dilution Station. Insert the short tube into your container and push up on the container to activate or push up on the grey button on the face of the Dilution Station. To fill a large container, use the long hose on the left side of the Dilution Station. Place the hose end in the container and push the button on the black gas pump style handle. (hose does not automatically shut off when container is full).

LockNLoad products are designed to be used with the LockNLoad Dispensing Station. The product should be loaded into the Dispensing Station and locked into place. Using the Dispensing Station will ensure that the concentrate is diluted correctly at 64:1. One gallon of LockNLoad Concentrate makes 64 gallons of ready to use product.

The grey dilution lock in the opening of the container should never be removed. If the dilution lock has been removed, the contents of the container and the container should be properly disposed of.

PRECAUTIONARY STATEMENTS

Prevention: Wear eye protection/face protection. **Response:** IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/doctor/medical professional.