



# Sour/Soft

## LAUNDRY SOFTENER & NEUTRALIZER



### PHYSICAL PROPERTIES

**Appearance:** Milky Pink Liquid

**Specific Gravity:** 1.09

**Odor:** Pleasant

**Ph (Conc.):** 1-2

**Flash Point:** >212°F (100°C)

### PACKAGING

4X1 gal

### ABOUT THIS PRODUCT

Helps reduce drying time by helping linen reduce moisture retention while neutralizing the pH of detergents. A combination softener and sour. The softening ability controls static electricity, reduces wrinkling, and imparts a smooth, soft finish to fabrics. The sour portion of this product controls pH levels of finished linen.

**Dual Job:** Softens fabric and reduces residual alkalinity.

**Antistatic:** Imparts anti-static properties to linen.

**Reduces Wrinkling:** Softening of the fabric reduces wrinkling.

**Brightens Fabrics:** Optical brightener renews brightness of white and colored Fabrics.

**Pleasant Fragrance:** Leaves a fresh, clean fragrance in linens.

**Can Be Used On Most Fabrics:** Use on all cottons, linens and synthetic fabrics.

**APPLICATIONS:** Recommended for use with automatic laundry equipment in: hotels, motels, hospitals, nursing homes, commercial laundries, restaurants, and other on-premise laundries.

**DO NOT USE ON 100% POLYESTER TABLE LINENS.**

**CAUTION:** Overuse will cause waterproofing.

### DIRECTIONS

Use Sour/Soft in the wash cycle at 1-2 ozs. Per 100 pounds of laundry. The optimum pH of the finished laundry should be 5.5 to 6.5.

### PRECAUTIONARY STATEMENTS

**Prevention:** Do not breathe dusts or mists. Wash hands and exposed skin thoroughly after handling. Wear protective gloves/protective clothing/eye protection/face protection. **Response:** IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower. Wash contaminated clothing before reuse. IF INHALED: Remove person to fresh air and keep comfortable breathing. Immediately call a POISON CENTER/doctor/medical professional. Specific treatment (see Section 4 on the Safety Data Sheet). IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. **Storage:** Store locked up. **Disposal:** Dispose of contents/container in accordance with local/ regional/ national/international regulations.